2-1. EXPLODED VIEWS

2-1-1. REAR SECTION-1

① 1

③ 3

② 2

#112

#2

Rear Section-2
(See page 2-4)

5 -1

#2

When installing, adjust this position.

#2

5 -2

④ 4

⑤ 5

(Claws)

#2

#1

2-1-2. REAR SECTION-2

⑤ 54

Main Board Section
(See page 2-5)

⑤-1

#2

#2

#2

Slide and Pull

#12

55

② 52

#12

④ 53

③ LCD Section
(See page 2-11)

① 51

2-1-3. MAIN BOARD SECTION

ns: not supplied

ILCE-7/7K

*Overall Section
(ILCE-7/7K)
(See page 2-7)*

#12

② *TOP Section
(See page 2-12)*

2

104

LCD902
(Note 2)

① 101

103

102

#2
ILCE-7R

#1
ILCE-7/7K

*Overall Section
(ILCE-7R)
(See page 2-6)*

When removing and re-assembling,
pull this connector vertically from the board.

106

BT0601
(Note 1)

#2

③ 105
(Note 2)

ILCE-7R

BH0601
(Note 1)

ns

*: BT0601 (LITHIUM SECONDARY BATTERY)
Board on the mount position.
(See page 6-47 of Level 3)*

#11

2-1-4. OVERALL SECTION (ILCE-7R)

ns: not supplied

When removing and re-assembling,
pull this connector vertically from the board.

#2

#2

154

157

155

156

ns

ns

ns

② *ANT901*

(Claws)

③ *ANT101*

④ *Battery Block Section*
(See page 2-13)

160

#2

⑥ *Imager Block Section*
(See page 2-8)

152

#2

158

⑤ 159

153

(Claws)

(Claws)

#2

① 151

2-1-5. OVERALL SECTION (ILCE-7/7K)

ns: not supplied

When removing and re-assembling,
pull this connector vertically from the board.

206

#2

208

207

(Claws)

ns

ns

ns

③ ANT901

④ ANT101

⑤ *Battery Block Section*
(See page 2-13)

211

#2

⑦ *Imager Block Section*
(See page 2-8)

#12

#2

① **201**

#12

#12

202

212

#12

⑥ **210**

(Claws)

(Claws)

204

209

205

#2

② **203**

2-1-6. IMAGER BLOCK SECTION

ns: not supplied

258

257

254
(Note 2, 3)

Mount Section
(See page 2-10)

253
(including IC6101 (CMOS imager)
and IS-111 complete board)
(Note 4)

③ 256

④ 255

254
(Note 2, 3)

#238

#197

252

251

254
(Note 2, 3)

① *ns*

② *Imager Unit Section*
(See page 2-9)

#267
(Note 1)

#267
(Note 1)

ns