

## Digital Still Camera

### Compatibility Chart

- This "Compatibility Chart" only provides compatibility testing results for the Memory Stick media applications listed in each product's instruction manual with Memory Stick media types listed below.
- This chart may be changed along with specification change. Please confirm your product compatibility in this chart.
- Recording time and the number of still images varies by host hardware devices. For details, refer to the instruction manual of your device.
- This chart does not guarantee support for all Memory Stick media types' performance nor compatibility among Memory Stick media compliant products.
- Memory Stick media transmission speed varies by, and depends on, host hardware devices' features and circumstances of use.
- Attach a dedicated adapter to use Memory Stick Duo™ media in a slot for standard size media.
- Attach a dedicated adapter to use Memory Stick Micro™ media in a slot for Memory Stick PRO devices.
- Models listed in this colour are discontinued.
- The Memory Stick media capacity indicated on the packaging will differ from actual usable capacity. A portion of the memory is used for data management file functions. Refer to the back of the packaging for the minimum guaranteed capacity. Click [here](#) to view the Memory Stick media user capacity chart.

[Memory Stick & Memory Stick Duo](#) | [Memory Stick PRO & Memory Stick PRO Duo](#) | [Memory Stick Pro Duo \(Mark 2\)](#) | [Memory Stick Pro \(High Speed\)](#) | [Memory Stick PRO Duo \(High Speed\)](#) | [Memory Stick PRO-HG Duo](#) | [Memory Stick Duo \(with MagicGate\)](#) | [Memory Stick PRO Duo \(PSP-MP1G\)](#) |

### Remarks

Remarks:

- \*1 Data over 123MB cannot be recorded in a single session.
- \*2 Transmission speed may not be faster when using Memory Stick PRO(High Speed/Mark2) and Memory Stick PRO-HG.
- \*3 Please disregard the 'Busy' message which may appear on the LCD screen during MPEG movie recording in VX Fine mode. Recording and playback operations, as well as recorded data, will not be affected.
- \*4 A dedicated adapter (MSAC-M2) must be attached to use Memory Stick Duo™ or MagicGate Memory Stick Duo media.
- \*5 The MSAC-MMS adapter must be attached to use the Memory Stick Micro™ media in a slot for standard size Memory Stick Pro media. Compatibility is not guaranteed when using the MSAC-MMD adapter in combination with another adapter.
- \*6 The MSAC-MMD adapter must be attached to use Memory Stick Micro™ media in a slot for Duo size Memory Stick Pro media.
- \*7 This product is made by Sony Computer Entertainment Inc.
- \*8 This media is not compatible with MPEG movie VX Fine mode.
- \*9 The file system incorporated in the Memory Stick limits the capacity of a file to be recorded or played back to less than 4GB.

### Legend

- X - No compatibility
- O - Only data that does not require copyright protection function (MagicGate) can be recorded/played back
- © - Data that requires copyright protection (MagicGate) can be recorded/played back
- Not guaranteed
- ! - Discontinued

Last Updated 11th August 2009

### Memory Stick PRO Duo (Mark2) / Memory Stick PRO (High Speed) / Memory Stick PRO Duo (High Speed) / Memory Stick PRO HG Duo

Media Category	Memory Stick PRO Duo (Mark2) *2					Memory Stick PRO (High Speed) *2		Memory Stick PRO Duo (High Speed) *2 *2		Memory Stick PRO HG Duo	
Model Name	MS-MT1G / MT2G	MS-MT4G	MS-MT8G	MS-MT16G	MS-MT32G	MSX-256N / 512N / 1GN / 2GN	MSX-4GN	MSX-M256N / M512N / M1GN / M2GN	MS-EX1G / EX2G (without Duo STD adaptor)	MS-EX4G (without Duo STD adaptor)	
Memory Size	1GB/2GB	4GB	8GB *9	16GB *9	32GB *9	256MB/512MB /1GB/2GB	4GB	256MB/512MB /1GB/2GB	1GB/2GB	4GB	

### CyberShot

DSC-F505V	x	x	x	x	x	x	x	x	x	x	x
DSC-F707	x	x	x	x	x	x	x	x	x	x	x
DSC-F717	O*4	x	x	x	x	O	x	O*4	-	x	
DSC-F77	O*4	x	x	x	x	O	x	O*4	-	x	
DSC-F77A	O*4	x	x	x	x	O	x	O*4	-	-	-
DSC-F828	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-	-
DSC-F88	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-	-
DSC-FX77	O*4	x	x	x	x	O	x	O*4	-	x	
DSC-G1	O	O*8	O*8	O*8	O*8	x	x	O	O	O	O*8
DSC-G3	O	O	O	O	O	x	x	O	O	O	O
DSC-H1	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-	
DSC-H10	O	O	O	O	O	x	x	O	O	O	O
DSC-H2	O	O*8	x	x	x	x	x	O	-	-	
DSC-H20	O	O	O	O	O	x	x	O	O	O	O
DSC-H3	O	O	O	O*8	O*8	x	x	O	O	O	O*8
DSC-H5	O	O*8	x	x	x	x	x	O	-	-	

Model Name	MS-MT1G / MT2G	MS-MT4G	MS-MT8G	MS-MT16G	MS-MT32G	MSX-256N / 512N / 1GN / 2GN	MSX-4GN	MSX-M256N / M512N / M1GN / M2GN	MS-EX1G / EX2G (without Duo STD adaptor)	MS-EX4G (without Duo STD adaptor)
SC-H50	O	O	O	O	O	x	x	O	O	O
DSC-H7	O	O*8	O*8	O*8	O*8	x	x	O	O	O*8
DSC-H9	O	O*8	O*8	O*8	O*8	x	x	O	O	O*8
DSC-HX1	O	O	O	O	O	x	x	O	O	O
DSC-L1	O*3	O*8*10	x	x	x	x	x	O	-	-
DSC-N1	O	O*8	x	x	x	x	x	O	-	-
DSC-N2	O	O*8	x	x	x	x	x	O	-	-
DSC-P1	x	x	x	x	x	x	x	x	x	x
DSC-P10	O*4	x	x	x	x	O	x	O*4	-	x
DSC-P100	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-
DSC-P12	O*4	x	x	x	x	O	x	O*4	-	x
DSC-P120	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-
DSC-P150	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-
DSC-P2	x	x	x	x	x	x	x	x	x	x
SC-P20	x	x	x	x	x	x	x	x	x	x
DSC-P200	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-
DSC-P3	x	x	x	x	x	x	x	x	x	x
DSC-P30	x	x	x	x	x	x	x	x	x	x
DSC-P31	x	x	x	x	x	x	x	x	x	x
DSC-P32	O*4	x	x	x	x	O	x	O*4	-	x
DSC-P41	O*3*4	O*4*8*10	x	x	x	O	O*8	O*4	-	-
DSC-P43	O*3*4	O*4*8*10	x	x	x	O	O*8	O*4	-	-
DSC-P5	x	x	x	x	x	x	x	x	x	x
DSC-P50	x	x	x	x	x	x	x	x	x	x
DSC-P51	x	x	x	x	x	x	x	x	x	x
DSC-P52	O*4	x	x	x	x	O	x	O*4	-	x
DSC-P7	x	x	x	x	x	x	x	x	x	x
DSC-P71	x	x	x	x	x	x	x	x	x	x
DSC-P72	O*4	x	x	x	x	O	x	O*4	-	x
DSC-P73	O*3*4	O*4*8*10	x	x	x	O	O*8	O*4	-	-
DSC-P8	O*4	x	x	x	x	O	x	O*4	-	x
DSC-P9	x	x	x	x	x	x	x	x	x	x
DSC-P92	O*4	x	x	x	x	O	x	O*4	-	x
DSC-P93	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-
DSC-R1	O*4	O*4*8	x	x	x	O	O*8	O*4	-	-
DSC-S40	O*3*4	O*4*8*10	x	x	x	O	O*8	O*4	-	-
DSC-S500	O	x	x	x	x	x	x	O	-	-
DSC-S60	O*3*4	O*4*8*10	x	x	x	O	O*8	O*4	-	-
DSC-S600	O	O*8	x	x	x	x	x	O	-	-
DSC-S650	O	O*8	x	x	x	x	x	O	-	-
DSC-S700	O	O*8	x	x	x	x	x	O	-	-
DSC-S730	O	O	O	x	x	x	x	O	O	O
DSC-S75	x	x	x	x	x	x	x	x	x	x
DSC-S750	O	O	O	O	O	x	x	O	O	O
DSC-S780	O	O	O	O	O	x	x	O	O	O
DSC-S80	O*3*4	O*4*8*10	x	x	x	O	O*8	O*4	-	-
DSC-S800	O	O*8	O*8	x	x	x	x	O	O	O*8
DSC-S85	x	x	x	x	x	x	x	x	x	x
DSC-S90	O*3*4	O*4*8*10	x	x	x	O	O*8	O*4	-	-
DSC-S930	O	O	O	O	O	x	x	O	O	O
DSC-S950	O	O	O	O	O	x	x	O	O	O
DSC-S980	O	O	O	O	O	x	x	O	O	O
DSC-ST80	O*3*4	O*4*8*10	x	x	x	O	O*8	O*4	-	-
DSC-T1	O	O*8	x	x	x	x	x	O	-	-
DSC-T10	O	O*8	x	x	x	x	x	O	-	-
DSC-T100	O	O*8	O*8	O*8	O*8	x	x	O	O	O*8
DSC-T11	O	O*8	x	x	x	x	x	O	-	-
DSC-T2	O	O	O	O	O	x	x	O	O	O
DSC-T20	O	O*8	O*8	O*8	O*8	x	x	O	O	O*8
DSC-T200	O	O*8	O*8	O*8	O*8	x	x	O	O	O*8
DSC-T25	O	O*8	O*8	O*8	O*8	x	x	O	O	O*8
DSC-T3	O	O*8	x	x	x	x	x	O	-	-
DSC-T30	O	O*8	x	x	x	x	x	O	-	-
DSC-T300	O	O	O	O	O	x	x	O	O	O



**Memory Stick Pro HG Duo HX / Memory Stick Duo (with MagicGate) / Memory Stick PRO Duo (PSP-MP1G) / Memory Stick Micro (M2)**

Media Category	Memory Stick PRO-HG Duo HX *2				Memory Stick Duo	Memory Stick PRO	Memory Stick Micro (M2)				
					(with MagicGate)	Duo					
											
Model Name	MS-HX4G	MS-HX8G	MS-HX16G	MS-HX32G	PSP-M32 *2 (without Duo STD adaptor)	PSP-MP1G *2 (without Duo STD adaptor)	MS-A256A / A512A / A1GA MS-A256W / A512W / A1GW MS-A512N / A1GN MS-A512U / A1GU	MS-A2GW MS-A2GN MS-A2GU	MS-A4GW MS-A4GN MS-A4GU	MS-A8GN MS-A8GU2	MS-A16GU2
Memory Size	4G	8G	16G	32GB *9	32MB	1GB	256MB/512MB/1GB	2GB	4GB	8GB	16GB
CyberShot											
DSC-F505V	x	x	x	x	O*4	x	x	x	x	x	x
DSC-F707	x	x	x	x	O*4	x	x	x	x	x	x
DSC-F717	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-F77	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-F77A	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-F828	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-F88	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-FX77	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-G1	O*8	O*8	O*8	O*8	O	O	O*6	-	-	-	-
DSC-G3	O	O	O	O	O	O	O*6	O*6	O*6	O*6	O*6
DSC-H1	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-H10	O	O	O	O	O	O	O*6	O*6	O*6	O*6	O*6
DSC-H2	-	x	x	x	O	O	O*6	-	-	x	-
DSC-H20	O	O	O	O	O	O	O*6	O*6	O*6	O*6	O*6
DSC-H3	O*8	O*8	O*8	O*8	O	O	O*6	O*6	O*6	O*6	O*6
DSC-H5	-	x	x	x	O	O	O*6	-	-	x	-
DSC-H50	O	O	O	O	O	O	O*6	O*6	O*6	O*6	O*6
DSC-H7	O*8	O*8	O*8	O*8	O	O	O*6	-	-	-	-
DSC-H9	O*8	O*8	O*8	O*8	O	O	O*6	-	-	-	-
DSC-HX1	O	O	O	O	x	O	O*6	O*6	O*6	O*6	O*6
DSC-L1	-	x	x	x	O	O*3	O*6	-	-	x	-
DSC-N1	-	x	x	x	O	O	O*6	-	-	x	-
DSC-N2	-	x	x	x	O	O	O*6	-	-	x	-
DSC-P1	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P10	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P100	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P12	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P120	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P150	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P2	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P20	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P200	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P3	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P30	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P31	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P32	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P41	-	x	x	x	O*4	O*3*4	O*5	-	-	x	-
DSC-P43	-	x	x	x	O*4	O*3*4	O*5	-	-	x	-
DSC-P5	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P50	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P51	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P52	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P7	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P71	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P72	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P73	-	x	x	x	O*4	O*3*4	O*5	-	-	x	-
DSC-P8	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P9	x	x	x	x	O*4	x	x	x	x	x	x
DSC-P92	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-P93	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-R1	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-S40	-	x	x	x	O*4	O*3*4	O*5	-	-	x	-
DSC-S500	-	x	x	x	O	O	O*6	-	-	x	-
DSC-S60	-	x	x	x	O*4	O*3*4	O*5	-	-	x	-

Model Name	MS-HX4G	MS-HX8G	MS-HX16G	MS-HX32G	PSP-M32 *2 (without Duo STD adaptor)	PSP-MP1G *2 (without Duo STD adaptor)	MS-A256A / A512A / A1GA MS-A256W / A512W / A1GW MS-A512N / A1GN MS-A512U / A1GU	MS-A2GW MS-A2GN MS-A2GU	MS-A4GW MS-A4GN MS-A4GU	MS-A8GN MS-A8GU2	MS-A16GU2
DSC-S600	-	x	x	x	o	o	O*6	-	-	x	-
DSC-S650	-	x	x	x	o	o	O*6	-	-	-	-
DSC-S700	-	x	x	x	o	o	O*6	-	-	-	-
DSC-S730	o	o	o	o	o	o	O*6	-	-	-	-
DSC-S75	x	x	x	x	O*4	x	x	x	x	x	x
DSC-S750	o	o	o	o	o	o	O*6	O*6	-	-	-
DSC-S780	o	o	o	o	o	o	O*6	O*6	-	-	-
DSC-S80	-	x	x	x	O*4	O*3*4	O*5	-	-	-	-
DSC-S800	O*8	O*8	O*8	O*8	o	o	O*6	-	-	-	-
DSC-S85	x	x	x	x	O*4	x	x	x	x	x	x
DSC-S90	-	x	x	x	O*4	O*3*4	O*5	-	-	-	-
DSC-S930	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-S950	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-S980	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-ST80	-	x	x	x	O*4	O*3*4	O*5	-	-	x	-
DSC-T1	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T10	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T100	O*8	O*8	O*8	O*8	o	o	O*6	-	-	-	-
DSC-T11	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T2	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-T20	O*8	O*8	O*8	O*8	o	o	O*6	-	-	-	-
DSC-T200	O*8	O*8	O*8	O*8	o	o	O*6	O*6	O*6	O*6	o*6
DSC-T25	O*8	O*8	O*8	O*8	o	o	O*6	-	-	-	-
DSC-T3	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T30	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T300	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-T33	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T5	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T50	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T500	o	o	o	-	o	o	O*6	O*6	O*6	O*6	o*6
DSC-T7	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T70	O*8	O*8	O*8	O*8	o	o	O*6	O*6	O*6	O*6	o*6
DSC-T700	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-T77	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-T9	-	x	x	x	o	o	O*6	-	-	x	-
DSC-T90	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-T900	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-TX1	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-V1	x	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-V3	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-W1	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-W100	-	x	x	x	o	o	O*6	-	-	x	-
DSC-W110	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W12	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-W120	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W130	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W15	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-W150	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W17	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-W170	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W180	o	o	o	-	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W190	o	o	o	-	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W200	O*8	O*8	O*8	O*8	o	o	O*6	-	-	-	-
DSC-W210	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W220	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W230	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W270	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W290	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W30	-	x	x	x	o	o	O*6	-	-	x	-
DSC-W300	o	o	o	o	o	o	O*6	O*6	O*6	O*6	o*6
DSC-W35	-	-	-	-	o	o	O*6	-	-	-	-
DSC-W40	-	x	x	x	o	o	O*6	-	-	x	-
DSC-W5	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-W50	-	x	x	x	o	o	O*6	-	-	x	-

Model Name	MS-HX4G	MS-HX8G	MS-HX16G	MS-HX32G	PSP-M32 *2 (without Duo STD adaptor)	PSP-MP1G *2 (without Duo STD adaptor)	MS-A256A / A512A / A1GA MS-A256W / A512W / A1GW MS-A512N / A1GN MS-A512U / A1GU	MS-A2GW	MS-A4GW	MS-A8GN	MS-A16GU2
DSC-W55	-	-	-	-	O	O	O*6	-	-	-	-
DSC-W7	-	x	x	x	O*4	O*4	O*5	-	-	x	-
DSC-W70	-	x	x	x	O	O	O*6	-	-	x	-
DSC-W80	O*8	O*8	O*8	O*8	O	O	O*6	-	-	-	-
DSC-W85	O*8	O*8	O*8	O*8	O	O	O*6	-	-	-	-
DSC-W90	O*8	O*8	O*8	O*8	O	O	O*6	-	-	-	-
DSC-WX1	O	O	O	O	O	O	O*6	O*6	O*6	O*6	O*6
<b>Cyber-shot U</b>											
DSC-U10	-	x	x	x	O*4	x	x	x	x	x	x
DSC-U20	-	x	x	x	O*4	x	x	x	x	x	x
DSC-U30	-	x	x	x	O*4	O*4	O*5	-	-	x	x
DSC-U40	-	x	x	x	O	O	O*6	-	-	x	x
DSC-U50	-	x	x	x	O	O	O*6	-	-	x	x
DSC-U60	-	x	x	x	O*4	O*4	O*5	-	-	x	x
<b>Cyber-shot M</b>											
DSC-M1	-	x	x	x	O	O	O*6	-	-	x	x
DSC-M2	-	x	x	x	O	O	O*6	-	-	x	x
<b>Mavica</b>											
MVC-FD100	-	x	x	x	O*4	x	x	x	x	x	x
MVC-FD200	-	x	x	x	O*4	x	x	x	x	x	x
MVC-FD92	-	x	x	x	O*4	x	x	x	x	x	x

#### Remarks

Remarks:

\*1 Data over 123MB cannot be recorded in a single session.

\*2 Transmission speed may not be faster when using Memory Stick PRO(High Speed/Mark2) and Memory Stick PRO-HG.

\*3 Please disregard the 'Busy' message which may appear on the LCD screen during MPEG movie recording in VX Fine mode.

Recording and playback operations, as well as recorded data, will not be affected.

\*4 A dedicated adapter (MSAC-M2) must be attached to use Memory Stick Duo™ or MagicGate Memory Stick Duo media.

\*5 The MSAC-MMS adapter must be attached to use the Memory Stick Micro™ media in a slot for standard size Memory Stick Pro media.

Compatibility is not guaranteed when using the MSAC-MMD adapter in combination with another adapter.

\*6 The MSAC-MMD adapter must be attached to use Memory Stick Micro™ media in a slot for Duo size Memory Stick Pro media.

\*7 This product is made by Sony Computer Entertainment Inc.

\*8 This media is not compatible with MPEG movie VX Fine mode.

\*9 The file system incorporated in the Memory Stick limits the capacity of a file to be recorded or played back to less than 4GB.

#### Legend

X - No compatibility

O - Only data that does not require copyright protection function (MagicGate) can be recorded/played back

© - Data that requires copyright protection (MagicGate) can be recorded/played back

— - Not guaranteed

! - Discontinued

Last Updated 11th August 2009

**Memory Stick PRO Duo (Mark2) / Memory Stick PRO (High Speed) / Memory Stick PRO Duo (High Speed) / Memory Stick PRO HG Duo**

Media Category	Memory Stick PRO Duo (Mark2)				Memory Stick PRO Duo (Mark2)	Memory Stick PRO (High Speed)	Memory Stick PRO Duo (High Speed)	Memory Stick PRO HG Duo
								
Model Name	MS-MT1G / MT2G / MT4G	MS-MT8G	MS-MT16G	MS-MT32G	MSX-256N / 512N / 1GN / 2GN	MSX-4GN	MSX-M256N / M512N / M1GN / M2GN	MS-EX1G / EX2G (without Duo STD adaptor)
Memory Size	1GB/2GB/4GB	8GB *6	16GB *6	32GB *6	256MB/512MB / 1GB/2GB	4GB	256MB/512MB/1GB/2GB	1GB/2GB
<b>Model Name</b>								
a100	O*3	O*3	x	-	x	x	O*3 *4	O*3*4
a200 *7	O*3	O*3	O*3	-	x	x	O*3 *4	O*3*4
a230	O	O	O	-	x	x	O	O
a300 *7	O*3	O*3	O*3	-	x	x	O*3 *4	O*3*4
a330	O	O	O	-	x	x	O	O
a350 *7	O*3	O*3	O*3	-	x	x	O*3 *4	O*3*4
a380	O	O	O	-	x	x	O	O
a700	O	O	O	-	x	x	O	O
a900	O	O	O	-	x	x	O	O

**Memory Stick PRO HG Duo HX / Memory Stick Duo (with MagicGate) / Memory Stick PRO Duo (PSP-MP1G) / Memory Stick Micro (M2)**

Media Category	Memory Stick PRO HG Duo HX				Memory Stick Duo (with MagicGate)	Memory Stick PRO Duo	Memory Stick Micro (M2)			
										
Model Name	MS-HX4G / MS-HX8G	MS-HX16G	MS-HX32G	PSP-M32 *2 (without Duo STD adaptor)	PSP-MP1G *2 (without Duo STD adaptor)	MS-A256A / A512A / A1GA MS-A256W / A512W / A1GW MS-A512N / A1GN MS-A512U / A1GU	MS-A2GW MS-A2GN MS-A2GU	MS-A4GN MS-A4GU	MS-A8GN MS-A8GU2	MS-A16GU2
Memory Size	4GB/8GB	16GB	32GB	32MB	1GB	256MB/512MB/1GB	2GB	4GB	8GB	16GB
<b>Model Name</b>										
a100	O*3*4	x	-	O*3	O*3	x	x	x	x	x
a200 *7	O*3*4	O*3*4	-	O*3	O*3	x	x	x	x	x
a230	O	O	-	x	O	O*5	O*5	O*5	O*5	O*5
a300 *7	O*3*4	O*3*4	-	O*3	O*3	x	x	x	x	x
a330	O	O	-	x	O	O*5	O*5	O*5	O*5	O*5
a350 *7	O*3*4	O*3*4	-	O*3	O*3	x	x	x	x	x
a380	O	O	-	x	O	O*5	O*5	O*5	O*5	O*5
a700	O	O	-	O	O	O*5	O*5	O*5	O*5	O*5
a900	O	O	-	O	O	O*5	O*5	O*5	O*5	O*5

**Remarks**

Remarks:

\*1 Data over 123MB cannot be recorded in a single session.

\*2 This product is made by Sony Computer Entertainment Inc.

\*3 To use a Memory Stick Duo™, use the ADMSCF1 Memory Stick adapter.

\*4 Transmission speed is restricted by the design of host hardware devices, equal to that of the Memory Stick PRO media.

\*5 The MSAC-MMD adapter must be attached to use Memory Stick Micro™ media in a slot for Duo size Memory Stick Pro media.

\*6 The file system incorporated in the Memory Stick limits the capacity of a file to be recorded or played back to less than 4GB.

\*7 The ADMSCF1 Memory Stick adaptor is sold separately.

**Legend**

X - No compatibility

O - Only data that does not require copyright protection function (MagicGate) can be recorded/played back

© - Data that requires copyright protection (MagicGate) can be recorded/played back

— - Not guaranteed

! - Discontinued

Last Updated 11th August 2009

**Memory Stick PRO HG Duo / Memory Stick PRO Duo (Mark2) / Memory Stick PRO (High Speed) / Memory Stick PRO Duo (High Speed) / Memory Stick PRO HG Duo HX**

Media Category	Memory Stick PRO Duo(Mark2) *7	Memory Stick PRO Duo *7	Memory Stick PRO (High Speed) *7	Memory Stick PRO Duo (High Speed) *7	Memory Stick PRO HG Duo HX *7				
									
Model Name	MS-MT1G / MT2G / MT4G / MT8G / MT16G	MS-MT32G	MSX-256N / 512N / 1GN / 2GN / 4GN	MSX-M256N / M512N / M1GN / M2GN	MS-EX4G (without Duo STD adaptor)	MS-HX4 / MS-HX8	MS-HX16G	MS-HX32G	
Memory Size	1GB/2GB/4GB/8GB *5/16GB *5	32GB *5	256MB/512MB /1GB/2GB/4GB	256MB/512MB/1GB/2GB	1GB/2GB	4GB	4GB/8GB	16GB	32GB

**Memory Stick Duo (with MagicGate) / Memory Stick PRO Duo (PSP-MP1G) / Memory Stick Micro (M2)**

Media Category	Memory Stick Duo (with MagicGate)	Memory Stick PRO Duo	Memory Stick Micro (M2)					
								
Model Name	PSP-M32 *6 (without Duo STD adaptor)	PSP-MP1G *6 (without Duo STD adaptor)	MS-A256A / A512A / A1GA MS-A256W / A512W / A1GW MS-A512N / A1GN MS-A512U / A1GU	MS-A2GW MS-A2GN MS-A2GU	MS-A4GW MS-A4GN MS-A4GU	MS-A8GN MS-A8GU2		MS-A16GU2
Memory Size	32MB	1GB	256MB/512MB/1GB	2GB	4GB	8GB		16GB

**Model Name**

DPF-D70	-	-	O*4	O*4	O*4	-	-
DPF-V700	-	-	O*4	O*4	O*4	-	-
DPF-V800	-	-	O	O	O	O	-
DPF-V900	O	-	O	O	O	O	O
DPF-V1000	O	-	O	O	O	O	-
DPF-X800	O	-	O	O	O	O	-
DPF-X1000	O	-	O	O	O	O	-
DPP-EX5	-	-	O*2	O*2	O*2	-	O*2
DPP-EX50	-	-	O	O*2	O*2	O*2	O*2
DPP-EX7	-	-	O	O*2	O*2	-	O*2
DPP-FP50	-	-	O	O	O	O	-
DPP-FP55	-	-	O	O	O	O	-
DPP-FP60	-	-	O	O	O	O	-
DPP-FP65	O	-	O	O	O	O	-
DPP-FP70	-	-	O	O	O	O	-
DPP-FP75	O	-	O	O	O	O	-
DPP-FP85	O	-	O	O	O	O	-
DPP-FP90	-	-	O	O	O	O	-
DPP-FP95	O	-	O	O	O	O	-
DPP-FP97	O	-	O	O	O	O	-
DPP-MP1	-	-	x	x	x	x	x
DPP-MS300	-	-	x	x	x	x	x
DPP-SV55	-	-	x	x	x	x	x
DPP-SV77	-	-	x	x	x	x	x
DPP-SV88	-	-	x	x	x	x	x

**Remarks**
**Remarks:**

\*1 Data over 123MB cannot be recorded in a single session.

\*2 A dedicated (MSAC-M2) adapter must be attached to use Memory Stick Duo™ or MagicGate Memory Stick Duo media.

\*3 The MSAC-MMS adapter must be attached to use the Memory Stick Micro™ media in a slot for standard size Memory Stick Pro media.

Compatibility is not guaranteed when using the MSAC-MMD adapter in combination with another adapter.

\*4 To use a Memory Stick Micro, attach a dedicated adaptor "MSAC-MMS" or "MSAC-MMD". Compatibility is not guaranteed when using the dedicated adaptor( MSAC-MMD ) combined with another adaptor.

\*5 The file system incorporated in the Memory Stick limits the capacity of a file to be recorded or played back to less than 4GB.

\*6 This product is made by Sony Computer Entertainment Inc.

\*7 Transmission speed may not be faster when using Memory Stick PRO(High Speed/Mark2) and Memory Stick PRO-HG.

\*8 Error message "This kind of Memory Stick can't be used" appears on the screen in spite that Memory Stick is formatted correctly.

**Legend**

X - No compatibility

O - Only data that does not require copyright protection function (MagicGate) can be recorded/played back

© - Data that requires copyright protection (MagicGate) can be recorded/played back

-- - Not guaranteed

! - Discontinued

**Handycam****Compatibility Chart**

- This "Compatibility Chart" only provides compatibility testing results for the Memory Stick media applications listed in each product's instruction manual with Memory Stick media types listed below.
- This chart may be changed along with specification change. Please confirm your product compatibility in this chart.
- This chart does not guarantee support for all Memory Stick media types' performance nor compatibility among Memory Stick media compliant products.
- Memory Stick media transmission speed varies by, and depends on, host hardware devices' features and circumstances of use.
- Attach a dedicated adapter to use a Memory Stick Duo media in a slot for standard size media.
- Attach a dedicated adapter to use Memory Stick Micro™ media in a slot for Memory Stick PRO devices.
- Models listed in orange colour are discontinued.
- The Memory Stick media capacity indicated on the packaging will differ from actual usable capacity. A portion of the memory is used for data management file functions. Refer to the back of the packaging for the minimum guaranteed capacity. Click [here](#) to view the Memory Stick media user capacity chart.

[Memory Stick & Memory Stick Duo](#) | [Memory Stick PRO & Memory Stick PRO Duo](#) | [Memory Stick Pro Duo \(Mark 2\)](#) | [Memory Stick Pro \(High Speed\)](#) | [Memory Stick PRO Duo \(High Speed\)](#) | [Memory Stick PRO-HG Duo](#) | [Memory Stick Duo \(with MagicGate\)](#) | [Memory Stick PRO Duo \(PSP-MP1G\)](#) | [Memory Stick Micro\(M2\)](#)

**Memory Stick (with MagicGate) / Memory Stick Duo (with MagicGate) / Memory Stick PRO & Memory Stick PRO Duo**

Media Category	Memory Stick (with MagicGate)	Memory Stick Duo (with MagicGate)	Memory Stick PRO			Memory Stick PRO Duo			
									
Model Name	MSH-32 / 64 / 128 / 128S2*1	MSH-M32N / M64N / M128N *1	MSX-256S / 512S / 1GS	MSX-1GST	MSX-2GS	MSX-M256S / M512S / M1GS	MSX-M1GST / M2GS	MSX-M4GS	MSX-M8GS
Memory Size	32MB/64MB /128MB	32MB/64MB /128MB	256MB/512MB/1GB	1GB	2GB	256MB/512MB/1GB	1GB/2GB	4GB	8GB *9
<b>Digital Video Camera</b>									
DCR-DVD608/E	x	o	x	x	x	o	o	o	o
DCR-DVD608/E	x	o	x	x	x	o	o	o	o
DCR-DVD610	x	o *11	x	x	x	o *12	o	o	o
DCR-DVD610E	x	o *11	x	x	x	o *12	o	o	o
DCR-DVD650 /E	x	o *11	x	x	x	o *13	o	o	o
DCR-DVD708/E	x	o	x	x	x	o	o	o	o
DCR-DVD708/E	x	o	x	x	x	o	o	o	o
DCR-DVD710	x	o *11	x	x	x	o *12	o	o	o
DCR-DVD710E	x	o *11	x	x	x	o *12	o	o	o
DCR-DVD755/E	x	o	x	x	x	o	o	o	o
DCR-DVD805/E	x	o	x	x	x	o	o	o	o
DCR-DVD808/E	x	o	x	x	x	o	o	o	o
DCR-DVD810	x	o *11	x	x	x	o *12	o	o	o
DCR-DVD810E	x	o *11	x	x	x	o *12	o	o	o
DCR-DVD850 /E	x	o *11	x	x	x	o *13	o	o	o
DCR-DVD905/E	x	o	x	x	x	o	o	o	o
DCR-DVD908/E	x	o	x	x	x	o	o	o	o
DCR-DVD910	x	o *11	x	x	x	o *12	o	o	o
DCR-DVD910E	x	o *11	x	x	x	o *12	o	o	o
DCR-HC1000/E	x	o	x	x	x	o	o	o*14	x
DCR-HC30/E	x	o	x	x	x	o	o	o*14	x
DCR-HC32/E	x	o	x	x	x	o	o	o*14	x
DCR-HC33E	x	o	x	x	x	o	o	o*14	x
DCR-HC36/E	x	o	x	x	x	o	o	o	x
DCR-HC40/E	x	o	x	x	x	o	o	o*14	x
DCR-HC42/E	x	o	x	x	x	o	o	o*14	x
DCR-HC43E	x	o	x	x	x	o	o	o*14	x
DCR-HC46/E	x	o	x	x	x	o	o	o*14	x
DCR-HC48/E	x	o	x	x	x	o	o	o	o
DCR-HC62	x	o	x	x	x	o	o	o	o
DCR-HC62E	x	o	x	x	x	o	o	o	o
DCR-HC65	x	o	x	x	x	o	o	o*14	x
DCR-HC85/E	x	o	x	x	x	o	o	o*14	x
DCR-HC90/E	x	o	x	x	x	o	o	o*14	x
DCR-HC96/E	x	o	x	x	x	o	o	o*14	x
DCR-IP1/E	x	o	x	x	x	o	o	x	x
DCR-IP210/E	o	o *6	x	x	x	x	x	x	x
DCR-IP220/E	o	o *6	x	x	x	x	x	x	x
DCR-IP45/E	o	o *6	x	x	x	x	x	x	x
DCR-IP55/E	o	o *6	x	x	x	x	x	x	x
DCR-IP7/E	o	o *6	x	x	x	x	x	x	x
DCR-PC100/E	o *2 *5	o *2 *5 *6	x	x	x	x	x	x	x
DCR-PC1000/E	x	o	x	x	x	o	o	o*14	x
DCR-PC101/E	o	o *6	x	x	x	x	x	x	x
DCR-PC105/E	o	o *6	o	o	o	o *6	o *6	x	x
DCR-PC108/E	x	o	x	x	x	o	o	o*14	x
DCR-PC109/E	x	o	x	x	x	o	o	o*14	x
DCR-PC110/E	o	o *6	x	x	x	x	x	x	x
DCR-PC115/E	o	o *6	x	x	x	x	x	x	x
DCR-PC120/E	o	o *6	x	x	x	x	x	x	x
DCR-PC3/E	o *2 *5	o *2 *5 *6	x	x	x	x	x	x	x
DCR-PC330/E	o	o *6	o	o	o	o *6	o *6	x	x
DCR-PC350/E	x	o	x	x	x	o	o	o*14	x
DCR-PC5/E	o	o *6	x	x	x	x	x	x	x
DCR-PC55/E	x	o	x	x	x	o	o	o*14	x
DCR-PC9/E	o	o *6	x	x	x	x	x	x	x
DCR-SR200/E	x	o	x	x	x	o	o	o	o
DCR-SR220	x	o *11	x	x	x	o *12	o	o	o
DCR-SR220E	x	o *11	x	x	x	o *12	o	o	o
DCR-SR300/E	x	o	x	x	x	o	o	o	o
DCR-SR42/E	x	o	x	x	x	o	o	o	o
DCR-SR45	x	o *11	x	x	x	o *12	o	o	o
DCR-SR45E	x	o *11	x	x	x	o *12	o	o	o
DCR-SR46	x	o *11	x	x	x	o *12	o	o	o
DCR-SR46E	x	o *11	x	x	x	o *12	o	o	o
DCR-SR47 /E	x	o *11	x	x	x	o *13	o	o	o
DCR-SR62/E	x	o	x	x	x	o	o	o	o





DCR-SR65	x	O *11	x	x	x	O *12	o	o	o
DCR-SR65E	x	O *11	x	x	x	O *12	o	o	o
DCR-SR67 /E	x	O *11	x	x	x	O *13	o	o	o
DCR-SR68	x	O *11	x	x	x	O *13	o	o	o
DCR-SR68E	x	O *11	x	x	x	O *13	o	o	o
DCR-SR82/E	x	o	x	x	x	o	o	o	o
DCR-SR85	x	O *11	x	x	x	O *12	o	o	o
DCR-SR85E	x	O *11	x	x	x	O *12	o	o	o
DCR-SR87 /E	x	O *11	x	x	x	O *13	o	o	o
DCR-SR88	x	O *11	x	x	x	O *13	o	o	o
DCR-SR88E	x	O *11	x	x	x	O *13	o	o	o
DCR-SX40 /E	x	O *11	x	x	x	O *13	o	o	o
DCR-SX41 /E	x	O *11	x	x	x	O *13	o	o	o
DCR-SX43	x	O *11	x	x	x	O *13	o	o	o
DCR-SX43E	x	O *11	x	x	x	O *13	o	o	o
DCR-SX44	x	O *11	x	x	x	O *13	o	o	o
DCR-SX44E	x	O *11	x	x	x	O *13	o	o	o
DCR-SX60 /E	x	O *11	x	x	x	O *13	o	o	o
DCR-SX63	x	O *11	x	x	x	O *13	o	o	o
DCR-SX63E	x	O *11	x	x	x	O *13	o	o	o
DCR-SX83	x	O *11	x	x	x	O *13	o	o	o
DCR-SX83E	x	O *11	x	x	x	O *13	o	o	o
DCR-TRV10/E	O *2 *5	O *2 *5 *6	x	x	x	x	x	x	x
DCR-TRV11/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV17/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV18/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV22/E	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV25/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV27/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV30/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV320/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV33/E	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV330/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV340/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV350	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV355E	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV356E	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV38/E	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV40/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV460/E	o	O *6	o	o	o	O *6	O *6	O*6*14	x
DCR-TRV461E	o	O *6	o	o	o	O *6	O *6	O*6*14	x
DCR-TRV480/E	o	O *6	o	o	o	O *6	O *6	O*6*14	x
DCR-TRV50/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV520/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV530/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV60/E	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV720/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV730/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV740/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV75/E	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV80/E	o	O *6	o	o	o	O *6	O *6	x	x
DCR-TRV820/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV828E	o	O *6	x	x	x	x	x	x	x
DCR-TRV830/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV900/E	O *2 *4	O *2 *4 *6	x	x	x	x	x	x	x
DCR-TRV940/E	o	O *6	x	x	x	x	x	x	x
DCR-TRV950/E	o	O *6	x	x	x	x	x	x	x
DCR-VX2000/E	o	O *6	x	x	x	x	x	x	x
DCR-VX2100/E	o	O *6	x	x	x	x	x	x	x
DCR-VX2200E	x	o	x	x	x	o	o	o	o
HDR-AX2000	x	O *11	x	x	x	O *13	o	o	o
HDR-AX2000E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX100 /E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX110E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX12	x	O *11	x	x	x	O *13	o	o	o
HDR-CX12E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX150	x	O *11	x	x	x	O *13	o	o	o
HDR-CX150E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX300	x	O *11	x	x	x	O *13	o	o	o
HDR-CX350	x	O *11	x	x	x	O *13	o	o	o
HDR-CX350E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX350VE	x	O *11	x	x	x	O *13	o	o	o
HDR-CX500 /E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX500V /E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX520 /E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX520V /E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX550	x	O *11	x	x	x	O *13	o	o	o
HDR-CX550E	x	O *11	x	x	x	O *13	o	o	o
HDR-CX550VE	x	O *11	x	x	x	O *13	o	o	o
HDR-CX7/E	x	O *11	x	x	x	O *12	o	o	o
HDR-FX1000 /E	x	o	x	x	x	o	o	o	o
HDR-FX7/E	x	o	x	x	x	o	o	o	o
HDR-HC1/E	x	o	x	x	x	o	o	o	x
HDR-HC3/E	x	o	x	x	x	o	o	o	x

HDR-HC5/E	x	o	x	x	x	o	o	o	o
HDR-HC7/E	x	o	x	x	x	o	o	o	o
HDR-HC9	x	o	x	x	x	o	o	o	o
HDR-HC9E	x	o	x	x	x	o	o	o	o
HDR-SR1/E	x	o	x	x	x	o	o	o	o
HDR-SR10	x	o *11	x	x	x	o *13	o	o	o
HDR-SR10E	x	o *11	x	x	x	o *13	o	o	o
HDR-SR11	x	o *11	x	x	x	o *13	o	o	o
HDR-SR11E	x	o *11	x	x	x	o *13	o	o	o
HDR-SR12	x	o *11	x	x	x	o *13	o	o	o
HDR-SR12E	x	o *11	x	x	x	o *13	o	o	o
HDR-SR5/E	x	o	x	x	x	o	o	o	o
HDR-SR7/E	x	o	x	x	x	o	o	o	o
HDR-SR8/E	x	o	x	x	x	o	o	o	o
HDR-TG1	x	o *11	x	x	x	o *13	o	o	o
HDR-TG1E	x	o *11	x	x	x	o *13	o	o	o
HDR-TG5 /E	x	o *11	x	x	x	o *13	o	o	o
HDR-TG5V /E	x	o *11	x	x	x	o *13	o	o	o
HDR-UX1/E	x	o	x	x	x	o	o	o	o
HDR-UX10	x	o *11	x	x	x	o *13	o	o	o
HDR-UX10E	x	o *11	x	x	x	o *13	o	o	o
HDR-UX20	x	o *11	x	x	x	o *13	o	o	o
HDR-UX20E	x	o *11	x	x	x	o *13	o	o	o
HDR-UX5/E	x	o	x	x	x	o	o	o	o
HDR-UX7/E	x	o	x	x	x	o	o	o	o
HDR-XR100 /E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR150	x	o *11	x	x	x	o *13	o	o	o
HDR-XR150E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR200 /E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR200V /E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR350	x	o *11	x	x	x	o *13	o	o	o
HDR-XR350E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR350VE	x	o *11	x	x	x	o *13	o	o	o
HDR-XR500 /E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR500V /E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR520 /E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR520V /E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR550	x	o *11	x	x	x	o *13	o	o	o
HDR-XR550E	x	o *11	x	x	x	o *13	o	o	o
HDR-XR550VE	x	o *11	x	x	x	o *13	o	o	o
NEX-VG10E	x	o *11	x	x	x	o *13	o	o	o

**Portable Video Recorder**

GV-D1000/E	o	o *6	x	x	x	x	x	x	x
GV-HD700 /E	x	o	x	x	x	o	o	o	o

**Memory Stick PRO Duo (Mark2) / Memory Stick PRO (High Speed) / Memory Stick PRO Duo (High Speed) / Memory Stick PRO HG Duo**

Media Category	Memory Stick PRO Duo (Mark2) *3					Memory Stick PRO (High Speed) *3		Memory Stick PRO Duo (High Speed) *3		Memory Stick PRO HG Duo *3	
											

Model Name	MS-MT1G / MT2G	MS-MT4G	MS-MT8G	MS-MT16G	MS-MT32G	MSX-256N / 512N / 1GN / 2GN	MSX-4GN	MSX-M256N / M512N / M1GN / M2GN	MS-EX1G / EX2G (without Duo STD adaptor)	MS-EX4G (without Duo STD adaptor)
------------	----------------	---------	---------	----------	----------	-----------------------------	---------	---------------------------------	--	-----------------------------------

Memory Size	1GB/2GB	4GB	8GB *9	16GB *9	32GB *9	256MB/512MB /1GB/2GB	4GB	256MB/512MB /1GB/2GB	1GB/2GB	4GB
-------------	---------	-----	--------	---------	---------	----------------------	-----	----------------------	---------	-----


**Digital Video Camera**

DCR-DVD608/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD608/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD610	o	o	o	o	o	x	x	o *12	o	o
DCR-DVD610E	o	o	o	o	o	x	x	o *12	o	o
DCR-DVD650 /E	o	o	o	o	o	x	x	o *13	o	o
DCR-DVD708/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD708/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD710	o	o	o	o	o	x	x	o *12	o	o
DCR-DVD710E	o	o	o	o	o	x	x	o *12	o	o
DCR-DVD755/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD805/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD808/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD810	o	o	o	o	o	x	x	o *12	o	o
DCR-DVD810E	o	o	o	o	o	x	x	o *12	o	o
DCR-DVD850 /E	o	o	o	o	o	x	x	o *13	o	o
DCR-DVD905/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD908/E	o	o	o	o	o	x	x	o	o	o
DCR-DVD910	o	o	o	o	o	x	x	o *12	o	o
DCR-DVD910E	o	o	o	o	o	x	x	o *12	o	o
DCR-HC1000/E	o	o*14	x	x	x	x	x	o	o	o*14
DCR-HC30/E	o	o*14	x	x	x	x	x	o	o	o*14
DCR-HC32/E	o	o*14	x	x	x	x	x	o	o	o*14
DCR-HC33E	o	o*14	x	x	x	x	x	o	o	o*14
DCR-HC36/E	o	o	x	x	x	x	x	o	o	o
DCR-HC40/E	o	o*14	x	x	x	x	x	o	o	o*14
DCR-HC42/E	o	o*14	x	x	x	x	x	o	o	o*14
DCR-HC43E	o	o*14	x	x	x	x	x	o	o	o*14
DCR-HC46/E	o	o*14	x	x	x	x	x	o	o	o*14
DCR-HC48/E	o	o	o	o	o	x	x	o	o	o
DCR-HC62	o	o	o	o	o	x	x	o	o	o
DCR-HC62E	o	o	o	o	o	x	x</td			

DCR-HC90/E	O	O*14	x	x	x	x	x	O	O	O*14
DCR-HC96/E	O	O*14	x	x	x	x	x	O	O	O*14
DCR-IP1/E	O	x	x	x	x	x	x	O	O	x
DCR-IP210/E	x	x	x	x	x	x	x	x	x	x
DCR-IP220/E	x	x	x	x	x	x	x	x	x	x
DCR-IP45/E	x	x	x	x	x	x	x	x	x	x
DCR-IP55/E	x	x	x	x	x	x	x	x	x	x
DCR-IP7/E	x	x	x	x	x	x	x	x	x	x
DCR-PC100/E	x	x	x	x	x	x	x	x	x	x
DCR-PC1000/E	O	O*14	x	x	x	x	x	O	O	O*14
DCR-PC101/E	x	x	x	x	x	x	x	x	x	x
DCR-PC105/E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-PC108/E	O	O*14	x	x	x	x	x	O	O	O*14
DCR-PC109/E	O	O*14	x	x	x	x	x	O	O	O*14
DCR-PC110/E	x	x	x	x	x	x	x	x	x	x
DCR-PC115/E	x	x	x	x	x	x	x	x	x	x
DCR-PC120/E	x	x	x	x	x	x	x	x	x	x
DCR-PC3/E	x	x	x	x	x	x	x	x	x	x
DCR-PC330/E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-PC350/E	O	O*14	x	x	x	x	x	O	O	O*14
DCR-PC5/E	x	x	x	x	x	x	x	x	x	x
DCR-PC55/E	O	O*14	x	x	x	x	x	O	O	O*14
DCR-PC9/E	x	x	x	x	x	x	x	x	x	x
DCR-SR200/E	O	O	O	O	O	x	x	O	O	O
DCR-SR220	O	O	O	O	O	x	x	O *12	O	O
DCR-SR220E	O	O	O	O	O	x	x	O *12	O	O
DCR-SR300/E	O	O	O	O	O	x	x	O	O	O
DCR-SR42/E	O	O	O	O	O	x	x	O	O	O
DCR-SR45	O	O	O	O	O	x	x	O *12	O	O
DCR-SR45E	O	O	O	O	O	x	x	O *12	O	O
DCR-SR46	O	O	O	O	O	x	x	O *12	O	O
DCR-SR46E	O	O	O	O	O	x	x	O *12	O	O
DCR-SR47 /E	O	O	O	O	O	x	x	O *13	O	O
DCR-SR62/E	O	O	O	O	O	x	x	O	O	O
DCR-SR65	O	O	O	O	O	x	x	O *12	O	O
DCR-SR65E	O	O	O	O	O	x	x	O *12	O	O
DCR-SR67 /E	O	O	O	O	O	x	x	O *13	O	O
DCR-SR68	O	O	O	O	O	x	x	O *13	O	O
DCR-SR68E	O	O	O	O	O	x	x	O *13	O	O
DCR-SR82/E	O	O	O	O	O	x	x	O	O	O
DCR-SR85	O	O	O	O	O	x	x	O *12	O	O
DCR-SR85E	O	O	O	O	O	x	x	O *12	O	O
DCR-SR87 /E	O	O	O	O	O	x	x	O *13	O	O
DCR-SR88	O	O	O	O	O	x	x	O *13	O	O
DCR-SR88E	O	O	O	O	O	x	x	O *13	O	O
DCR-SX40 /E	O	O	O	O	O	x	x	O *13	O	O
DCR-SX41 /E	O	O	O	O	O	x	x	O *13	O	O
DCR-SX43	O	O	O	O	O	x	x	O *13	O	O
DCR-SX43E	O	O	O	O	O	x	x	O *13	O	O
DCR-SX44	O	O	O	O	O	x	x	O *13	O	O
DCR-SX44E	O	O	O	O	O	x	x	O *13	O	O
DCR-SX60 /E	O	O	O	O	O	x	x	O *13	O	O
DCR-SX63	O	O	O	O	O	x	x	O *13	O	O
DCR-SX63E	O	O	O	O	O	x	x	O *13	O	O
DCR-SX83	O	O	O	O	O	x	x	O *13	O	O
DCR-SX83E	O	O	O	O	O	x	x	O *13	O	O
DCR-TRV10/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV11/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV17/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV18/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV22/E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV25/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV27/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV30/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV320/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV33/E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV330/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV340/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV350	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV355E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV356E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV38/E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV40/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV460/E	O *6	O*6*14	x	x	x	O	O	O *6	O *6	O*6*14
DCR-TRV461E	O *6	O*6*14	x	x	x	O	O	O *6	O *6	O*6*14
DCR-TRV480/E	O *6	O*6*14	x	x	x	O	O	O *6	O *6	O*6*14
DCR-TRV50/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV520/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV530/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV60/E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV720/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV730/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV740/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV75/E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV80/E	O *6	x	x	x	x	O	x	O *6	O *6	x
DCR-TRV820/E	x	x	x	x	x	x	x	x	x	x
DCR-TRV828E	x	x	x	x	x	x	x	x	x	x
DCR-TRV830/E	x	x	x	x	x	x	x	x	x	x

DCR-TRV900/E	x	x	x	x	x	x	x	x	x	x	x
DCR-TRV940/E	x	x	x	x	x	x	x	x	x	x	x
DCR-TRV950/E	x	x	x	x	x	x	x	x	x	x	x
DCR-VX2000/E	x	x	x	x	x	x	x	x	x	x	x
DCR-VX2100/E	x	x	x	x	x	x	x	x	x	x	x
DCR-VX2200E	O	O	O	O	O	x	x	O	O	O	O
HDR-AX2000	O	O	O	O	O	x	x	O *13	O	O	O
HDR-AX2000E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX100 / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX110E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX12	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX12E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX150	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX150E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX300	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX350	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX350E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX350VE	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX500 / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX500V / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX520 / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX520V / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX550	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX550E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX550VE	O	O	O	O	O	x	x	O *13	O	O	O
HDR-CX7/E	O	O	O	O	O	x	x	O *12	O	O	O
HDR-FX1000 / E	O	O	O	O	O	x	x	O	O	O	O
HDR-FX7/E	O	O	O	O	O	x	x	O	O	O	O
HDR-HC1/E	O	O	x	x	x	x	x	O	O	O	O
HDR-HC3/E	O	O	x	x	x	x	x	O	O	O	O
HDR-HC5/E	O	O	O	O	O	x	x	O	O	O	O
HDR-HC7/E	O	O	O	O	O	x	x	O	O	O	O
HDR-HC9	O	O	O	O	O	x	x	O	O	O	O
HDR-HC9E	O	O	O	O	O	x	x	O	O	O	O
HDR-SR1/E	O	O	O	O	O	x	x	O	O	O	O
HDR-SR10	O	O	O	O	O	x	x	O *13	O	O	O
HDR-SR10E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-SR11	O	O	O	O	O	x	x	O *13	O	O	O
HDR-SR11E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-SR12	O	O	O	O	O	x	x	O *13	O	O	O
HDR-SR12E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-SR5/E	O	O	O	O	O	x	x	O	O	O	O
HDR-SR7/E	O	O	O	O	O	x	x	O	O	O	O
HDR-SR8/E	O	O	O	O	O	x	x	O	O	O	O
HDR-TG1	O	O	O	O	O	x	x	O *13	O	O	O
HDR-TG1E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-TG5 / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-TG5V / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-UX1/E	O	O	O	O	O	x	x	O	O	O	O
HDR-UX10	O	O	O	O	O	x	x	O *13	O	O	O
HDR-UX10E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-UX20	O	O	O	O	O	x	x	O *13	O	O	O
HDR-UX20E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-UX5/E	O	O	O	O	O	x	x	O	O	O	O
HDR-UX7/E	O	O	O	O	O	x	x	O	O	O	O
HDR-XR100 / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR150	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR150E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR200 / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR200V / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR350	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR350E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR350VE	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR500 / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR500V / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR520 / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR520V / E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR550	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR550E	O	O	O	O	O	x	x	O *13	O	O	O
HDR-XR550VE	O	O	O	O	O	x	x	O *13	O	O	O
NEX-VG10E	O	O	O	O	O	x	x	O *13	O	O	O
<b>Portable Video Recorder</b>											
GV-D1000/E	x	x	x	x	x	x	x	x	x	x	x
GV-HD700 / E	O	O	O	O	O	x	x	O	O	O	O

**Memory Stick PRO-HG Duo HX / Memory Stick Duo (with MagicGate) / Memory Stick PRO Duo (PSP-MP1G) / Memory Stick Micro (M2)**

Media Category	Memory Stick PRO-HG Duo HX *3								Memory Stick Duo (with MagicGate)	Memory Stick PRO Duo	Memory Stick Micro (M2)			
														
Model Name	MS-HX4G	MS-HX8G	MS-HX16G	MS-HX32G	MS-HX8A	MS-HX16A	MS-HX32A	PSP-M32 *10 (without Duo STD adaptor)	PSP-MP1G *10 (without Duo STD adaptor)	MS-A256A / A512A / A1GA MS-A256W / A512W / A1GW	MS-A2GW	MS-A4GW	MS-A4GN	MS-A8GN
										MS-A2GN	MS-A2GU	MS-A4GU	MS-A8GU2	MS-A16GN

Memory Size	4GB	8GB	16GB	32GB	8GB	16GB	32GB	32MB	1GB	256MB/512MB/1GB	2GB	4GB	8GB	16GB
<b>Digital Video Camera</b>														
DCR-DVD608/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD608/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD610	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8	O*8
DCR-DVD610E	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8	O*8
DCR-DVD650 /E	O	O	O	O	O	O	O	O*11	O	O*8 *11	O*8 *11	O*8 *11	O*8 *11	O*8 *11
DCR-DVD708/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD708/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD710	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8	O*8
DCR-DVD710E	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8	O*8
DCR-DVD755/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD805/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD808/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD810	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8	O*8
DCR-DVD810E	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8	O*8
DCR-DVD850 /E	O	O	O	O	O	O	O	O*11	O	O*8 *11	O*8 *11	O*8 *11	O*8 *11	O*8 *11
DCR-DVD905/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD908/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-DVD910	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8	O*8
DCR-DVD910E	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8	O*8
DCR-HC1000/E	O*14	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-HC30/E	O*14	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-HC32/E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-HC33E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-HC36/E	O	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8	x
DCR-HC40/E	O*14	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-HC42/E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-HC43E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-HC46/E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-HC48/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-HC62	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-HC62E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-HC65	O*14	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-HC85/E	O*14	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-HC90/E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-HC96/E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-IP1/E	x	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-IP210/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-IP220/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-IP45/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-IP55/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-IP7/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-PC100/E	x	x	x	x	x	x	x	x	O*5 *6	x	x	x	x	x
DCR-PC1000/E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-PC101/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-PC105/E	x	x	x	x	x	x	x	x	O*6	O*6	x	x	x	x
DCR-PC108/E	O*14	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-PC109/E	O*14	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-PC110/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-PC115/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-PC120/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-PC3/E	x	x	x	x	x	x	x	x	O*5 *6	x	x	x	x	x
DCR-PC330/E	x	x	x	x	x	x	x	x	O*6	O*6	x	x	x	x
DCR-PC350/E	O*14	x	x	x	x	x	x	x	O	O	x	x	x	x
DCR-PC5/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-PC55/E	O*14	x	x	x	x	x	x	x	O	O	O*8	O*8	O*8*14	x
DCR-PC9/E	x	x	x	x	x	x	x	x	O*6	x	x	x	x	x
DCR-SR200/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-SR220	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR220E	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR300/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-SR42/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-SR45	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR45E	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR46	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR46E	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR47 /E	O	O	O	O	O	O	O	O	O*11	O	O*8 *11	O*8 *11	O*8 *11	O*8 *11
DCR-SR62/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-SR65	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR65E	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR67 /E	O	O	O	O	O	O	O	O	O*11	O	O*8 *11	O*8 *11	O*8 *11	O*8 *11
DCR-SR68	O	O	O	O	O	O	O	O	O*11	O	O*8 *11	O*8 *11	O*8 *11	O*8 *11
DCR-SR68E	O	O	O	O	O	O	O	O	O*11	O	O*8 *11	O*8 *11	O*8 *11	O*8 *11
DCR-SR82/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
DCR-SR85	O	O	O	O	O	O	O	O	O*11	O	O*8 *12	O*8	O*8	O*8
DCR-SR85E														

DCR-SX83	O	O	O	O	O	O	O	O *11	O	O *8 *11				
DCR-SX83E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
DCR-TRV10/E	x	x	x	x	x	x	x	O*5 *6	x	x	x	x	x	x
DCR-TRV11/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV17/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV18/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV22/E	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV25/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV27/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV30/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV320/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV33/E	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV330/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV340/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV350	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV355E	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV356E	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV38/E	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV40/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV460/E	O*6*14	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV461E	O*6*14	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV480/E	O*6*14	x	x	x	x	x	x	O *6	O *6	O*7	O*7	O*7*14	x	x
DCR-TRV50/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV520/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV530/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV60/E	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV720/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV730/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV740/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV75/E	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV80/E	x	x	x	x	x	x	x	O *6	O *6	x	x	x	x	x
DCR-TRV820/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV828E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV830/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV900/E	x	x	x	x	x	x	x	O*4 *6	x	x	x	x	x	x
DCR-TRV940/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-TRV950/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-VX2000/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-VX2100/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
DCR-VX2200E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
HDR-AX2000	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-AX2000E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX100 /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX110E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX12	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX12E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX150	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX150E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX300	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX350	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX350E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX350VE	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX500 /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX500V /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX520 /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX520V /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX550	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX550E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX550VE	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-CX7/E	O	O	O	O	O	O	O	O *11	O	O *8 *12	O *8	O *8	O *8	O *8
HDR-FX1000 /E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
HDR-FX7/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
HDR-HC1/E	O	x	x	x	x	x	x	O	O	O*8	O*8	O*8	x	x
HDR-HC3/E	O	x	x	x	x	x	x	O	O	O*8	O*8	O*8	x	x
HDR-HC5/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
HDR-HC7/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
HDR-HC9	O	O	O	O	O	O	O	O	O	O *8				
HDR-HC9E	O	O	O	O	O	O	O	O	O	O *8				
HDR-SR1/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
HDR-SR10	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-SR10E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-SR11	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-SR11E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-SR12	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-SR12E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-SR5/E	O	O	O	O	O	O	O	O	O	O *8				
HDR-SR7/E	O	O	O	O	O</td									

HDR-UX5/E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8
HDR-UX7/E	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8	O*8
HDR-XR100 /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR150	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR150E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR200 /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR200V /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR350	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR350E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR350VE	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR500 /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR500V /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR520 /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR520V /E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR550	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR550E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
HDR-XR550VE	O	O	O	O	O	O	O	O *11	O	O *8 *11				
NEX-VG10E	O	O	O	O	O	O	O	O *11	O	O *8 *11				
<b>Portable Video Recorder</b>														
GV-D1000/E	x	x	x	x	x	x	x	O *6	x	x	x	x	x	x
GV-HD700 /E	O	O	O	O	O	O	O	O	O	O*8	O*8	O*8	O*8	O*8

**Remarks**

- \*1 Data over 123MB cannot be recorded in a single session.
- \*2 Memory Stick media with 128MB or 128MBX2 capacity are not compatible with this product type.
- \*3 Transmission speed may not be faster when using Memory Stick PRO(High Speed/Mark2) and Memory Stick PRO-HG.
- \*4 You can use the Memory Stick with a PC card adaptor. This product is not applicable for DCF system.
- \*5 This product recognizes 100MSDCF only.
- \*6 A dedicated adapter (MSAC-M2) must be attached to use Memory Stick Duo™ or MagicGate Memory Stick Duo media.
- \*7 The MSAC-MMS adapter must be attached to use the Memory Stick Micro™ media in a slot for standard size Memory Stick Pro media. Compatibility is not guaranteed when using the MSAC-MMD adapter in combination with another adapter.
- \*8 The MSAC-MMD adapter must be attached to use Memory Stick Micro™ media in a slot for Duo size Memory Stick Pro media. media.
- \*9 The file system incorporated in the Memory Stick limits the capacity of a file to be recorded or played back to less than 4GB.
- \*10 This product is made by Sony Computer Entertainment Inc.
- \*11 This Memory Stick may not be able to record or play video.
- \*12 Use 512MB or over Memory Stick media when shooting video.
- \*13 Use 1GB or over Memory Stick media when shooting video.
- \*14 The maximum file size for a single continuous recording is 2GB.

**Legend**

X - No compatibility  
 O - Only data that does not require copyright protection function (MagicGate) can be recorded/played back  
 © - Data that requires copyright protection (MagicGate) can be recorded/played back  
 — - Not guaranteed  
 ! - Discontinued

Last Updated 3rd September 2010